

DA

RESET




AUX SUPPLY
220V AC

Z

L

SENSOR

RELAY



+VE

NPN

PNP

-VE

NC

C

NO