

RESET



VE-

PNP

NPN

+VE

SENSOR

NO



C



NC



90-270V AC

RELAY